

Verosol Shutters

Use, Care and Maintenance

Verosol Shutters are unsurpassed for quality, appearance and structural rigidity. They are made to last, but like all home furnishings need proper care and maintenance to extend their working life.

Operating Verosol Shutters

- Before operating ensure the blades are closed.
- When opening bi-folding shutters, start in the centre staking the panels together as you work your way out.
- Never force bi-folding shutters open or closed, never swing or put weight on a hinge shutter.
- For Sliding Shutters ensure that the blades are closed before sliding, this will prevent the blades from clashing.
- Whenever possible, use the control stick to control light and view. If you must, adjust the blades by hand by moving two blades simultaneously and stop if you feel resistance.
- Never tilt one blade on its own, the stress may damage the control stick or the timber blade.
- For light reduction, try rubbing the blades closed. This works most effectively with Verosol's unique interlocking blades and provides a high level of room darkening.

Cleaning Verosol Shutters

- In coastal areas an accumulation of salt residue on your shutters may gradually breakdown the lacquer or paint. Wipe down blades with a damp cloth routinely to remove excess salt residue.

Please contact your Verosol Retailer if you have any further questions or concerns about your Verosol Blinds.

Roller Blinds

Pleated Blinds

Roman Blinds

Panel Blinds

Timber Shutters
& Blinds

Curtains

Venetian Blinds

Motorised Blinds